

Witura GSM phone summary for alarm trigger only.

- Step 1: Go into programming - ****123456#**
- Step 2: To reset - ***15*1#**
- Step 3: To set Admin phone 1 - ***1*019.....#**
Repeat phone 2 to 8 - ***2*012.....#**
- Step 4: To send SMS to phone 1 to 8 - ***18*1111111#**
Remark: option not to SMS,
key in 0 instead of 1.
- Step 5: To turn on input 1 - ***24*1101#**
To turn on input 2 - ***25*1101#**
To turn on input 3 - ***26*1101#**
- Step 6: Hang up phone to exit programming.
- Step 7: To change Display Text of SMS by phone,

Use one of the admin phone to send a command SMS message to the unit, e.g.
Key in ***USE1#Home Alarm Trigger** and send, a return message will
show **USE1=Home Alarm Trigger**